




COOKTOP PARTS

For Models: RF262LXSQ3, RF262LXST3, RF262LXSB3
(Designer White)(Designer Biscuit)(Black)

30" ELECTRIC FREESTANDING
SELF CLEAN RANGE




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9762996	Literature Instructions Installations Template, Anti-Tip	2	9763324	Cooktop White	3	8273992	Element, Surface 2500 W – LF/RF
	9757142	English/Spanish		9763325	Biscuit		8273994	1200 W – LR/RR
	9757143	English/French		9763326	Black	4	3196169	Screw
	9763001	Owners Manual				5	8272791	Bracket, Element
	W10133890	Tech Sheet				6	W10035930	Spring, Locator
	9762761	Safer Cooking Tips				7	3196170	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: RF262LXSQ3, RF262LXST3, RF262LXSB3

(Designer White)(Designer Biscuit)(Black)



Illus. No.	Part No.	DESCRIPTION
1		Endcap
	W10009040	White Left Hand
	W10009050	White Right Hand
	W10009060	Biscuit Left Hand
	W10009070	Biscuit Right Hand
	W10009080	Black Left Hand
	W10009090	Black Right Hand
2	9757609	Nameplate
3		Panel, Control
	9762018	White
	9762028	Biscuit
	9762029	Black

Illus. No.	Part No.	DESCRIPTION
4		Switch, Infinite
	3148954	LF/RF (Orange)
	3148951	LR/RR (Silver)
5		Light, Indicator
	8523265	Surface Unit (2)
6	3196068	Lens, Light (3)
7		Knob, Infinite (4)
	9761962	White
	9761963	Biscuit
	9761964	Black
8	W10134247	Shield, Heat


Illus. No.	Part No.	DESCRIPTION
9		Screw
	3196166	White
	8281194	Biscuit
	3196168	Black
10	8272473	Cover, Upper
11	8273564	Clip
12		Control, Range
	W10108220	White
	W10108240	Biscuit
	W10108230	Black
13	3196178	Screw
14	9762078	Brkt-Mntg., EOC
15	9762095	Brkt-Mntg, Console
16	3400882	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: RF262LXSQ3, RF262LXST3, RF262LXSB3

(Designer White)(Designer Biscuit)(Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: RF262LXSQ3, RF262LXST3, RF262LXSB3
(Designer White)(Designer Biscuit)(Black)

Illus. No.	Part No.	DESCRIPTION
1	9760407	Brkt – Mounting
2	8273905	Support, Corner LR
3		Panel, Side (2)
	8053830	White
	8272519	Biscuit
	8053832	Black
4	W10067840	Screw
5	8522416	Seal, Oven Door
6	9757340	Element, Broil
7	9758541	Element, Bake
8	9761301	Screen–Catalyst
9	9757239	Rod – Dr Switch
10	W10114344	Glide, Drawer Frnt
11	3196037	Foot, Front (2)
12	9761517	Clip,Door Mntg(2)
13	8054068	Tray, Insulation
14	3196576	Clip, Panel (6)
15	9760314	Rail, Base (2)
16	W10058460	Foot, Rear (2)

Illus. No.	Part No.	DESCRIPTION
17	3196548	Thermal, Fuse
18	3196172	Screw
19	3186116	Support, Oven (2)
20	3186034	Bracket, Service
21	9761958	Block, Terminal
22	8274034	Back, Main
23	9757262	Switch, Door
24	3196701	Light Socket Assy
25	311255	Bulb, Oven Light
26	9758701	Spacer – Door
27	8273902	Sensor, Oven
28	3196169	Screw
29	3196179	Screw
30	3196178	Screw
31	3400016	Screw
32	9758283	Cover, Box
33	W10107820	Latch Asy, Rear

Illus. No.	Part No.	DESCRIPTION
34	W10031780	Screw
35	3196566	Screw
36	W10078380	Rod, Latch
37	3196174	Screw
38	9758238	Retainer, Insul(2)
39	3196560	Screw (2)
40	9761299	Flue
41	9761013	Latch, Door
42	3195736	Support, Front (2)
43	3195987	Support, Corner RR
44	112432	Nut
45	9761490	Insulation, Foil
46	9761512	Clip, Mounting
47	3196168	Screw


INSULATION

8272616	Insulation, Wrap
8272612	Insulation, Back
8272613	Insulation, Vent

DRAWER & BROILER PARTS

For Models: RF262LXSQ3, RF262LXST3, RF262LXSB3

(Designer White)(Designer Biscuit)(Black)




Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (2)
2	9761031	Drawer, Storage
3	9758200	Bracket, Drawer(2)
4		Rivet, Push (2)
	3196813	Black
	3196814	White
	3196815	Almond
5		Panel, Drawer Frnt
	8053341	Black
	8053339	White
	8272501	Biscuit
6	8053334	Glide, Drawer (2)
7	3196168	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: RF262LXSQ3, RF262LXST3, RF262LXSB3

(Designer White)(Designer Biscuit)(Black)



Illus. No.	Part No.	DESCRIPTION
1	9762391	Trim, Top
	9761975	Black
	9761976	White
	9761976	Biscuit
2	3196164	Screw
3		Handle, Door
	9761983	Black
	9761982	White
	9761984	Biscuit
4	9761344	Liner, Door
5	9758162	Glass, Inner (2)
6	3186289	Frame, Glass
7	W10031790	Screw

Illus. No.	Part No.	DESCRIPTION
8	8272618	Insulation, Door
9	9761357	Retainer, Insul.
10	9761493	Hinge, Door
11		Glass, Outer Door
	W10075990	Black
	W10075980	White
	W10076000	Biscuit
12		Trim, Door Side
	W10128571	Black L.H.
	W10128562	Black R.H.
	W10128572	White L.H.
	W10128563	White R.H.
	W10128573	Biscuit L.H.
	W10131044	Biscuit R.H.

Illus. No.	Part No.	DESCRIPTION
13	3196160	Screw
14		Trim, Lower Door
	8523177	Black
	8523175	White
	8523178	Biscuit
15	W10031780	Screw
16	8522414	Seal, Window
17	3196794	Bracket, Window(2)
18	3196165	Screw
19	W10113759	Strap, Door

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: RF262LXSQ3, RF262LXST3, RF262LXSB3

(Designer White)(Designer Biscuit)(Black)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Following Parts Not Illustrated

SPLICING WIRES--25FT.

LENGTH

242828	Wire, Black	12 Ga. 150° c
242821	Wire, Blue	14 Ga. 150° c
242822	Wire, Brown	14 Ga. 150° c
242830	Wire, Brown	14 Ga. 200° c
242823	Wire, Green	14 Ga. 150° c
242824	Wire, Orange	14 Ga. 150° c
242825	Wire, Red	14 Ga. 150° c
242831	Wire, Red	14 Ga. 200° c
242827	Wire, Yellow	14 Ga. 150° c

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean(1/2 Pt)
261582	Grease

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

INSULATION

261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
240132	Insulation, Fiberglass (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2oz.)

72017	White
72107	Almond
511873	White Porcelain (2 Oz.)

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350956	Almond
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

ACCESSORY PARTS

241430	Foil, Aluminum Oven (18" x 25')
3191048	Cleaner, Glass
4396923	Pan, Broiler

ANTI-TIP KIT

W10017440	Anti-Tip Kit
-----------	--------------

WIRING HARNESS PARTS

W10111790	Harness, Wire (Cooktop Left)
W10111766	Harness, Wire (Cooktop Right)
W10084660	Harness, Wire (Sensor/Dr Switch)
8523279	Wire, Ground
3196154	Screw
W10111771	Harness, Wire (Main)
313660	Clip, Wire Ground
3196173	Screw
3196174	Screw (Grnd Wire / Back)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST